

# **Water shut off, Excess Water production Methodologies for Diagnose and Evaluate the Mechanisms**

*Author: Fahmi Abdalla  
Shadow T.L Reservoir Eng .*

*GNPOC*

## **ABSTRACT:**

Production data of Heglig field history for last ten-year shows that an alert have to be given. Heglig is now under fast water production. The creeping of it may lead to the reduction of ultimate recovery (UR) of the field. Maximum liquid rate by ESP pumping may increase oil production in a short time (half a year), it may cause serious water coning, which will reduce cumulative oil production and increase water treatment cost, and shutdown of the well in the long run.

For all reservoirs producing by dominant mechanism of bottom water drive like Heglig field, excess water production represents difficult operational problems.

Produced water will cost money and of no real value, the best thing is to leave it in reservoir.

Problem potential for coping with excess water production is always challenging task for field operators. The cost of handling and disposing produced water can significantly shorten the economic producing life of well. The hydrostatic pressure created by high fluid levels in the well is also detrimental to oil production.

The trend of water cut. Vs. cumulative oil production is suspected to be reasonable. Based on Heglig field performance and since the recovery factor about 22 % but less than 1/5 recoverable reserve can be pumped out before water cut goes beyond 50% was observed while the figure from the experience is 1/3.

Too high production rate may result in quick water coning and fast water fingering, which lower down the efficiency of water displacement, hence reducing the cumulative oil production and sharp water coning shape, if formed in most well in such a short period of development means large quantity of oil is left inter well undeveloped; and will complicated the oil/water distribution in Heglig field.

The two major sources of excess water production are coning and channelling. Water coning is a common problem encountered when reservoir is produced via bottom- water –drive mechanism. Fracture and high permeability streaks are the common causes of premature water break through during water floods.